



AMARI STOOL

Page 1



DIMENSIONS

Height: 43 cm

Width: 59 cm

Depth: 31 cm

LEAD TIME

6 - 8 weeks

FABRIC

1 metre of fabric required COM, based on a plain material. A large pattern repeat may require more.

LEATHER

1 square metre of useable leather required, COM (0.5 - 1no small hide approx).



ALL CARE & MAINTENANCE

Page 2

Please note that all the instructions below are suggested methods of care and maintenance. We are not responsible for any damage incurred whilst cleaning. Always try a cleaning method on a hidden area first.

UPHOLSTERY

We upholster all our seating using customer's own material/leather. Please refer to the care and maintenance instructions provided by the manufacturer.

LEATHER

For leather supplied by us for use on furniture, for example the Hugo Drinks Cabinet, simply dust with a dry cloth.

Do not use use polish or cleaning products as these will affect the finish.

Blot spills with a soft dry cloth. Do not rub. If necessary use a slightly damp soft cloth taking care not to soak the leather. Do not rub and do not use abrasive materials. Allow to air dry.

There are many specialised leather cleaning companies available if required.

Avoid direct sunlight and high temperatures as this will compromise the finish.

PU LACQUER FINISHES

For regular maintenance, dust lightly with a soft cloth following the timber's grain. Most blemishes can be wiped off gently with a soft dampened cloth, again following the timber's grain. Do not rub with abrasive materials or use detergents or solvents.

Do not use furniture wax and/or spray polishes as these will affect the finish.

Anything with a rough or abrasive underside, for example cups or plates, will scratch the finish, however slightly. Always use soft base coasters.

Avoid direct sunlight and high temperatures as this will compromise the finish.



ALL CARE & MAINTENANCE

Page 3

PAINT LACQUER FINISHES

For regular maintenance, dust lightly with a soft cloth. Most blemishes can be wiped off gently with a soft dampened cloth. Do not rub with abrasive materials or use detergents or solvents.

Do not use furniture wax and/or spray polishes as these will affect the finish.

Anything with a rough or abrasive underside, for example cups or plates, will scratch the finish, however slightly. Always use soft base coasters.

Avoid direct sunlight and high temperatures as this will compromise the finish.

FRENCH POLISH FINISHES

For regular maintenance, dust lightly with a soft dry cloth following the timber's grain. Do not use a dampened cloth. Wipe up any spillages quickly as liquids compromise French polish. Do not rub with abrasive materials or use detergents or solvents.

Clear wax can be used which will add a little shine. The only products to use are pure, clear furniture waxes by quality brands. It is important not to use waxes with cleaning agents or turpentine. The wax should be applied sparingly with a soft cloth following the timber's grain and wiped off quickly before it dries. Application will be easier if the wax is warm. Buff to shine using a clean dry soft cloth, again following the timber's grain.

Do not use spray polishes as these will affect the finish.

Anything with a rough or abrasive underside, for example cups or plates, will scratch the finish, however slightly. Always use soft base coasters.

Avoid direct sunlight and high temperature as this will compromise the finish.